

Series	Manufacturer	Model	Number	Cable			
Acer							
	Acer	Aspire	AS3620	502285			
	Acer	Aspire	AS3623	502285			
	Acer	Aspire	1414	502938			
	Acer	Aspire	1800 Series	X			
	Acer	TravelMate	200	502285			
	Acer	TravelMate	220	502285			
	Acer	TravelMate	230	502285			
	Acer	TravelMate	260	502285			
	Acer	TravelMate	270	502285			
	Acer	TravelMate	240	X			
	Acer	TravelMate	250	X			
	Acer	TravelMate	280	502285			
	Acer	TravelMate	290 series	502285			
	Acer	TravelMate	314 XMI	502285			
	Acer	TravelMate	350	502285			
	Acer	TravelMate	400	502285			
	Acer	TravelMate	420	X			
	Acer	TravelMate	430	X			
	Acer	TravelMate	520 series	502285			
	Acer	TravelMate	600 Series	502285			
	Acer	TravelMate	620	502285			
	Acer	TravelMate	630	502285			
	Acer	TravelMate	650	502285			
	Acer	TravelMate	660	502285			
	Acer	TravelMate	730	502285			
	Acer	TravelMate	800	502285			
	Acer	TravelMate	1500 Series	X			
	Acer	TravelMate	1600 Series	X			
	Acer	TravelMate	1700 Series	X			
	Acer	TravelMate	2312 LCI	502938			
	Acer	TravelMate	2413 LCI	502285			
	Acer	TravelMate	3002 WLMi	502285			
	Acer	TravelMate	3003	502285			
	Acer	TravelMate	4001 LCI	502285			
	Acer	TravelMate	4062 WLCi	502285			
	Acer	TravelMate	4101 LCI	502285			
	Acer	TravelMate	4151 LCI	502285			
	Acer	TravelMate	4500 LCI	502285			
	Acer	TravelMate	8002 LCI	502285			
	Acer	TravelMate	Tablet PC TMC104TCI	502285			
	Acer	TravelMate	Tablet PC TMC104TI	502285			
	Acer	TravelMate	Tablet PC 110	502285			
	Acer	TravelMate	Tablet PC 111	502285			
	Acer	TravelMate	Tablet PC c100	502285			
	Acer	TravelMate	Tablet PC c100 TCI	502285			
	Acer	TravelMate	Tablet PC c102 TCI	502285			
	Acer	TravelMate	Tablet PC c113 TCI	502285			
	Acer	TravelMate	Tablet PC c301 XCIG	502285			
	Acer	TravelMate	Tablet PC C302 XCI	502285			
	Acer	TravelMate	Tablet PC c303 XMI	502285			
Altex							
	Altex	Wistron Centrino	1555-GL	502285			
Apple							
	Apple	iBook Dual USB	G3 Crystal White 12-inch	502435			
	Apple	iBook Dual USB	G3 Crystal White 14-inch	502435			
	Apple	iBook Dual USB	G4 12-inch	502435			
	Apple	iBook Dual USB	G4 14-inch	502435			
	Apple	PowerBook	G4 Series	502435			
	Apple	PowerBook	G4 12-inch Aluminum	502435			
	Apple	PowerBook	G4 15-inch Aluminum	502435			
	Apple	PowerBook	G4 15-inch Titanium	502435			
	Apple	MacBook Pro	Intel 15-inch Titanium	X			
Asus							
	Asus		Z 71V	502938			

Series	Manufacturer	Model	Number	Cable			
	Asus		A254	502938			
	Averatec						
	Averatec		1120	502938			
	Averatec		3150	502938			
	Averatec		3200	502938			
	Averatec		3500	502938			
	Averatec		5100	502938			
	Benq						
	Benq		8160	502938			
	Best						
	Best		2150	502938			
	Compaq						
	Compaq	Armada	1750	X			
	Compaq	Armada	4200 Series	X			
	Compaq	Armada	5000 Series	X			
	Compaq	Armada	100	X			
	Compaq	Armada	100S	X			
	Compaq	Armada	110	X			
	Compaq	Armada	7300	X			
	Compaq	Armada	7400	X			
	Compaq	Armada	E500	502936			
	Compaq	Armada	E700	502936			
	Compaq	Armada	M300	502936			
	Compaq	Armada	M700	502936			
	Compaq	Armada	V300 Series	502936			
	Compaq	Evo	N110	502936			
	Compaq	Evo	N115	502936			
	Compaq	Evo	N150	502936			
	Compaq	Evo	N160	502936			
	Compaq	Evo	N200	502936			
	Compaq	Evo	N400 Series	502936			
	Compaq	Evo	N600 Series	502936			
	Compaq	Evo	N800 Series	502936			
	Compaq	Evo	N800C Series	502936			
	Compaq	Evo	N800W Series	502936			
	Compaq	Evo	N1000 Series	502517			
	Compaq	Evo	TC 1000 Tablet	502936			
	Compaq	Evo	TC 1100 Tablet	502936			
	Compaq	Evo	TC 4200 Tablet	502936			
	Compaq	Evo	TC 4400 Tablet (65 watt models only)	503101			
	Compaq	Presario	1000 Series	502936			
	Compaq	Presario	1200 Series	502936			
	Compaq	Presario	12XL Series	502936			
	Compaq	Presario	1400	502936			
	Compaq	Presario	1500 Series	502517			
	Compaq	Presario	1600 Series	502936			
	Compaq	Presario	1600s Series	502936			
	Compaq	Presario	1700 Series	502936			
	Compaq	Presario	17XL Series	502936			
	Compaq	Presario	1800 Series	502936			
	Compaq	Presario	1800t Series	502936			
	Compaq	Presario	18XL Series	502936			
	Compaq	Presario	2700 Series	502936			
	Compaq	Presario	2800 Series	502936			
	Compaq	Presario	3000 Series	502936			
	Compaq	Presario	53xx / 54xx	X			
	Compaq	Presario	700	502936			
	Compaq	Presario	710	502936			
	Compaq	Presario	710 US	502936			
	Compaq	Presario	715 US	502936			
	Compaq	Presario	716 EA	502936			
	Compaq	Presario	732 US	502936			
	Compaq	Presario	734RSH	502936			
	Compaq	Presario	800	502936			
	Compaq	Presario	2100US Series	502936			

Series	Manufacturer	Model	Number	Cable			
	Compaq	Presario	2204US Series	502936			
	Compaq	Presario	3000US-3009US	502936			
	Compaq	Presario	3010US-30xxUS	X			
	Compaq	Presario	B3800	502936			
	Compaq	Presario	L2005	502936			
	Compaq	Presario	N105	502936			
	Compaq	Presario	N160	502936			
	Compaq	Presario	N180	502936			
	Compaq	Presario	R3425	X			
	Compaq	Presario	V2000	502936			
	Compaq	Presario	V4000	502936			
	Compaq	Presario	M2000	502936			
	Compaq	Presario	X1000 Series	502936			
Dell							
	Dell	Inspiron	300m	502986			
	Dell	Inspiron	400m	502986			
	Dell	Inspiron	500m	502986			
	Dell	Inspiron	600m	502986			
	Dell	Inspiron	630m	502986			
	Dell	Inspiron	700m	502986			
	Dell	Inspiron	1100	X			
	Dell	Inspiron	1150	X			
	Dell	Inspiron	1200	502938			
	Dell	Inspiron	1300	502938			
	Dell	Inspiron	2100	X			
	Dell	Inspiron	2200	502938			
	Dell	Inspiron	2500	502692			
	Dell	Inspiron	2600	502692			
	Dell	Inspiron	2650	502692			
	Dell	Inspiron	3000	502938			
	Dell	Inspiron	3200	502938			
	Dell	Inspiron	3500	502938			
	Dell	Inspiron	3700	502692			
	Dell	Inspiron	3800	502692			
	Dell	Inspiron	4000	502692			
	Dell	Inspiron	4100	502692			
	Dell	Inspiron	4150	502692			
	Dell	Inspiron	5000	502692			
	Dell	Inspiron	5100	X			
	Dell	Inspiron	5150	X			
	Dell	Inspiron	6000	502986			
	Dell	Inspiron	7000	502938			
	Dell	Inspiron	7500	502692			
	Dell	Inspiron	8000	502692			
	Dell	Inspiron	8100	502692			
	Dell	Inspiron	8200	502692			
	Dell	Inspiron	8500 Series	502986			
	Dell	Inspiron	8600 Series	502986			
	Dell	Inspiron	9200 Series	502986			
	Dell	Inspiron	9300 Series	502986			
	Dell	Inspiron	B130	502938			
	Dell	Inspiron	XPS M1210	502986			
	Dell	Inspiron	XPS / M140	X			
	Dell	Inspiron	XPS / M170	X			
	Dell	Inspiron	110L	502938			
	Dell	Inspiron	120L	502938			
	Dell	Inspiron	131L	502938			
	Dell	Latitude	L Series	X			
	Dell	Latitude	LS Series	X			
	Dell	Latitude	CP Series	502692			
	Dell	Latitude	Cpi Series	502692			
	Dell	Latitude	CPT Series	502692			
	Dell	Latitude	CPx Series	502692			
	Dell	Latitude	CS	502692			
	Dell	Latitude	CSx	502692			

Series	Manufacturer	Model	Number	Cable			
	Dell	Latitude	C400 Series	502692			
	Dell	Latitude	C500 Series	502692			
	Dell	Latitude	C600 Series	502692			
	Dell	Latitude	C610 Series	502692			
	Dell	Latitude	C640 Series	502692			
	Dell	Latitude	C800 Series	502692			
	Dell	Latitude	C810 Series	502692			
	Dell	Latitude	C840	502692			
	Dell	Latitude	D400	502986			
	Dell	Latitude	D410	502986			
	Dell	Latitude	D500	502986			
	Dell	Latitude	D520	502986			
	Dell	Latitude	D600	502986			
	Dell	Latitude	D610	502986			
	Dell	Latitude	D620	502986			
	Dell	Latitude	D800	502986			
	Dell	Latitude	D810	502986			
	Dell	Latitude	D820	502986			
	Dell	Latitude	X200	502692			
	Dell	Latitude	X300	502986			
	Dell	Latitude	LT Series	X			
	Dell	Latitude	XP Series	X			
	Dell	Latitude	XPI Series	X			
	Dell	Latitude	110L	502938			
	Dell	Latitude	120L	502938			
	Dell	Latitude	131L	502986			
	Dell	Precision	M20	502986			
	Dell	Precision	M40	502692			
	Dell	Precision	M50	502692			
	Dell	Precision	M60	502986			
	Dell	Precision	M65	502986			
	Dell	Precision	M70	502986			
	Dell	Precision	M90	X			
Desktop Evolution							
	Desktop Evolution		Helium 2100	502938			
ECS Elitegroup							
	ECS Elitegroup	Green	553	502938			
Elite PC							
	Elite PC		G320	502938			
Emachines							
	Emachines		M5305	502938			
	Emachines		M6810	502938			
FIC							
	FIC		MB-02	502938			
Fujitsu							
	Fujitsu	Amilio	L1300	502938			
	Fujitsu	Celsius	Mobile H	502938			
	Fujitsu	LifeBook	200 Series	502442			
	Fujitsu	LifeBook	400 Series	502442			
	Fujitsu	LifeBook	500 Series	502442			
	Fujitsu	LifeBook	700 Series	502442			
	Fujitsu	LifeBook	A Series	502442			
	Fujitsu	LifeBook	L Series	502442			
	Fujitsu	LifeBook	Stylistic 3400	502442			
	Fujitsu	LifeBook	Stylistic 3500	502442			
	Fujitsu	LifeBook	Stylistic 4000	502442			
	Fujitsu	LifeBook	Stylistic LT C-500	502442			
	Fujitsu	LifeBook	Stylistic LT P-600	502442			
	Fujitsu	LifeBook	565Tx	502442			
	Fujitsu	LifeBook	585Tx1	502442			
	Fujitsu	LifeBook	635T	502442			
	Fujitsu	LifeBook	635Tx1	502442			
	Fujitsu	LifeBook	655Tx	502442			
	Fujitsu	LifeBook	656Tx1	502442			
	Fujitsu	LifeBook	6575	502442			

Series	Manufacturer	Model	Number	Cable			
	Fujitsu	LifeBook	675Tx	502442			
	Fujitsu	LifeBook	690Tx	502442			
	Fujitsu	LifeBook	7020D	502938			
	Fujitsu	LifeBook	985Tx	502442			
	Fujitsu	LifeBook	990Tx2	502442			
	Fujitsu	LifeBook	B-2545	502442			
	Fujitsu	LifeBook	B-2562	502442			
	Fujitsu	LifeBook	B-2566	502442			
	Fujitsu	LifeBook	B-2630	502442			
	Fujitsu	LifeBook	B-3010	502442			
	Fujitsu	LifeBook	B-3020	502442			
	Fujitsu	LifeBook	C1020	502938			
	Fujitsu	LifeBook	C1410	502938			
	Fujitsu	LifeBook	C2010	502938			
	Fujitsu	LifeBook	C2110	502938			
	Fujitsu	LifeBook	C2111	502938			
	Fujitsu	LifeBook	C2210	502938			
	Fujitsu	LifeBook	C2220	502938			
	Fujitsu	LifeBook	C2230	502938			
	Fujitsu	LifeBook	C2240	502938			
	Fujitsu	LifeBook	C2310	502938			
	Fujitsu	LifeBook	C2330	502938			
	Fujitsu	LifeBook	C340	502442			
	Fujitsu	LifeBook	C350	502442			
	Fujitsu	LifeBook	C352	502442			
	Fujitsu	LifeBook	C353	502442			
	Fujitsu	LifeBook	C360	502442			
	Fujitsu	LifeBook	C-4120	502442			
	Fujitsu	LifeBook	C-4235	502442			
	Fujitsu	LifeBook	C-5130	502442			
	Fujitsu	LifeBook	C-5235	502442			
	Fujitsu	LifeBook	C-6177	502442			
	Fujitsu	LifeBook	C-6320	502442			
	Fujitsu	LifeBook	C-6330	502442			
	Fujitsu	LifeBook	C-6525	502442			
	Fujitsu	LifeBook	C-6535	502442			
	Fujitsu	LifeBook	C-6537	502442			
	Fujitsu	LifeBook	C-6547	502442			
	Fujitsu	LifeBook	C-6556	502442			
	Fujitsu	LifeBook	C-6557	502442			
	Fujitsu	LifeBook	C-6577	502442			
	Fujitsu	LifeBook	C-6581	502442			
	Fujitsu	LifeBook	C-6591	502442			
	Fujitsu	LifeBook	C-6611	502442			
	Fujitsu	LifeBook	C-6631	502442			
	Fujitsu	LifeBook	C-6651	502442			
	Fujitsu	LifeBook	C-7631	502442			
	Fujitsu	LifeBook	C-7651	502442			
	Fujitsu	LifeBook	C-7661	502442			
	Fujitsu	LifeBook	E330	502938			
	Fujitsu	LifeBook	E380	502938			
	Fujitsu	LifeBook	E-2000 series	502938			
	Fujitsu	LifeBook	E-4000 series	502938			
	Fujitsu	LifeBook	E-5140	502442			
	Fujitsu	LifeBook	E-5320	502442			
	Fujitsu	LifeBook	E-5520	502442			
	Fujitsu	LifeBook	E-6000 series	502938			
	Fujitsu	LifeBook	E-6150	502442			
	Fujitsu	LifeBook	E-6520	502442			
	Fujitsu	LifeBook	E-6530	502442			
	Fujitsu	LifeBook	E-6540	502442			
	Fujitsu	LifeBook	E-6541	502442			
	Fujitsu	LifeBook	E-6550	502442			
	Fujitsu	LifeBook	E-6556	502442			
	Fujitsu	LifeBook	E-6557	502442			

Series	Manufacturer	Model	Number	Cable			
	Fujitsu	LifeBook	E-6570	502442			
	Fujitsu	LifeBook	E-6571	502442			
	Fujitsu	LifeBook	E-6595	502442			
	Fujitsu	LifeBook	E-7000 series	502938			
	Fujitsu	LifeBook	E-8000 series	502938			
	Fujitsu	LifeBook	E-8110	502938			
	Fujitsu	LifeBook	P-1032	502442			
	Fujitsu	LifeBook	P-1035	502442			
	Fujitsu	LifeBook	P-1120	502442			
	Fujitsu	LifeBook	P-1510	502442			
	Fujitsu	LifeBook	P-1610	502442			
	Fujitsu	LifeBook	P-2040	502442			
	Fujitsu	LifeBook	P-2046	502442			
	Fujitsu	LifeBook	P-2110	502442			
	Fujitsu	LifeBook	P-2120	502442			
	Fujitsu	LifeBook	P-5020	502442			
	Fujitsu	LifeBook	P-7000	502442			
	Fujitsu	LifeBook	P-7010 D	502442			
	Fujitsu	LifeBook	S-2020	502442			
	Fujitsu	LifeBook	S-4010	502938			
	Fujitsu	LifeBook	S-4510	502442			
	Fujitsu	LifeBook	S-4542	502442			
	Fujitsu	LifeBook	S-5582	502442			
	Fujitsu	LifeBook	S-6010	502442			
	Fujitsu	LifeBook	S-6110	502442			
	Fujitsu	LifeBook	S-6120	502442			
	Fujitsu	LifeBook	S-6210	502442			
	Fujitsu	LifeBook	S-6220	502442			
	Fujitsu	LifeBook	S-6231	502442			
	Fujitsu	LifeBook	S-6240	502442			
	Fujitsu	LifeBook	S-7000	502938			
	Fujitsu	LifeBook	S-7010 D	502938			
	Fujitsu	LifeBook	N Series	X			
	Fujitsu	LifeBook	I Series	502442			
	Fujitsu	Stylistic	ST5032	502442			
	Fujitsu	Tablet	3500	502442			
	Fujitsu	Tablet	4110	502442			
	Fujitsu	Tablet	LTP 600	502442			
	Fujitsu	Tablet	ST 4000	502442			
	Fujitsu	Tablet	ST 4120	502442			
	Fujitsu	Tablet	ST 5000D	502442			
	Fujitsu	Tablet	ST 5010	502442			
	Fujitsu	Tablet	ST 5011	502442			
	Fujitsu	Tablet	ST 5020	502442			
	Fujitsu	Tablet	ST 5021	502442			
	Fujitsu	Tablet	ST 5022	502442			
	Fujitsu	Tablet	ST 5110	502442			
	Fujitsu	Tablet	T 3000	502442			
	Fujitsu	Tablet	T 3010	502442			
	Fujitsu	Tablet	T 4000	502938			
	Fujitsu	Tablet	T 4010	502938			
	Fujitsu	Tablet	T 4215	502938			
			Gateway				
	Gateway	Solo	200	502537			
	Gateway	Solo	200ARC	X			
	Gateway	Solo	200E	X			
	Gateway	Solo	200STM	X			
	Gateway	Solo	200X	X			
	Gateway	Solo	400	502537			
	Gateway	Solo	450	502537			
	Gateway	Solo	450E	502537			
	Gateway	Solo	600	502537			
	Gateway	Solo	1100 Series	502537			
	Gateway	Solo	1200 Series	502938			
	Gateway	Solo	1450	502537			

Series	Manufacturer	Model	Number	Cable			
	Gateway	Solo	2100 Series	502537			
	Gateway	Solo	2150 Series	502537			
	Gateway	Solo	2200 Series	502537			
	Gateway	Solo	2300 Series	502537			
	Gateway	Solo	2500 Series	502537			
	Gateway	Solo	2550 Series	502537			
	Gateway	Solo	3100 Series	502537			
	Gateway	Solo	3150 Series	502537			
	Gateway	Solo	3450	X			
	Gateway	Solo	4335 GZ	502938			
	Gateway	Solo	5100 Series	502537			
	Gateway	Solo	5150 Series	502537			
	Gateway	Solo	5300 Series	502537			
	Gateway	Solo	7422 GX	502938			
	Gateway	Solo	9100 Series	502537			
	Gateway	Solo	9300 Series	502537			
	Gateway	Solo	9500 Series	502537			
	Gateway	Solo	M305CRV	502537			
	Gateway	Solo	M350	X			
	Gateway	Solo	M275	502537			
	Gateway	Solo	M280 E	502938			
	Gateway		M405	502537			
	Gateway		M460	502938			
	Gateway		M465	502938			
	Gateway	Solo	M505	502537			
	Gateway		MX6956	502938			
	Gateway		NX5005	502537			
			Higrade				
	Higrade	Higrade	W6700	502938			
			Hewlett Packard				
	Hewlett Packard	Omnibook	800CT	X			
	Hewlett Packard	Omnibook	2000	X			
	Hewlett Packard	Omnibook	2100	502936			
	Hewlett Packard	Omnibook	3000	502936			
	Hewlett Packard	Omnibook	3100	502936			
	Hewlett Packard	Omnibook	4100	502936			
	Hewlett Packard	Omnibook	4150	502936			
	Hewlett Packard	Omnibook	500	502936			
	Hewlett Packard	Omnibook	510	502936			
	Hewlett Packard	Omnibook	5000	X			
	Hewlett Packard	Omnibook	5500	X			
	Hewlett Packard	Omnibook	5700	X			
	Hewlett Packard	Omnibook	6000	502936			
	Hewlett Packard	Omnibook	6100	502936			
	Hewlett Packard	Omnibook	7100 Series	502936			
	Hewlett Packard	Omnibook	7150	502936			
	Hewlett Packard	Omnibook	900	502936			
	Hewlett Packard	Omnibook	XE	502936			
	Hewlett Packard	Omnibook	XE2	502936			
	Hewlett Packard	Omnibook	XE3	502936			
	Hewlett Packard	Omnibook	XH485	502936			
	Hewlett Packard	Omnibook	XT6050	502936			
	Hewlett Packard	Omnibook	XT6200	502936			
	Hewlett Packard	Omnibook	VT6200	502936			
	Hewlett Packard	Omnibook	XE4100	502936			
	Hewlett Packard	Omnibook	XE4500	502936			
	Hewlett Packard	Omnibook	XT 1000 Series	502936			
	Hewlett Packard	Pavillion	DV 1000	502936			
	Hewlett Packard	Pavillion	DV 1040	502936			
	Hewlett Packard	Pavillion	DV 1100	502936			
	Hewlett Packard	Pavillion	DV 1200	502936			
	Hewlett Packard	Pavillion	DV 4000 Series	502936			
	Hewlett Packard	Pavillion	DV 5000 Series	502936			
	Hewlett Packard	Pavillion	DV 6000 Series	502936			
	Hewlett Packard	Pavillion	DV 8000	X			

Series	Manufacturer	Model	Number	Cable			
	Hewlett Packard	Pavillion	43xx	502936			
	Hewlett Packard	Pavillion	N3000 Series	502936			
	Hewlett Packard	Pavillion	N5000 Series	502936			
	Hewlett Packard	Pavillion	N5100 Series	502936			
	Hewlett Packard	Pavillion	N5200 Series	X			
	Hewlett Packard	Pavillion	N5300 Series	X			
	Hewlett Packard	Pavillion	N5400 Series	502936			
	Hewlett Packard	Pavillion	XZ148	502936			
	Hewlett Packard	Pavillion	ZD7000	X			
	Hewlett Packard	Pavillion	ZE1110	502936			
	Hewlett Packard	Pavillion	ZE2000	502936			
	Hewlett Packard	Pavillion	ZE4000	502936			
	Hewlett Packard	Pavillion	ZE4145	502936			
	Hewlett Packard	Pavillion	ZE4200	502936			
	Hewlett Packard	Pavillion	ZE4300	X			
	Hewlett Packard	Pavillion	ZE4400	X			
	Hewlett Packard	Pavillion	ZE4500	X			
	Hewlett Packard	Pavillion	ZE4900 Series	502936			
	Hewlett Packard	Pavillion	ZE50xx Series	502936			
	Hewlett Packard	Pavillion	ZE51xx Series	502936			
	Hewlett Packard	Pavillion	ZE52xx Series	502936			
	Hewlett Packard	Pavillion	ZE5270	X			
	Hewlett Packard	Pavillion	ZE53xx Series	X			
	Hewlett Packard	Pavillion	ZE54xx Series	X			
	Hewlett Packard	Pavillion	ZE55xx Series	X			
	Hewlett Packard	Pavillion	ZT Series	502936			
	Hewlett Packard	Pavillion	ZV5000	X			
	Hewlett Packard	Pavillion	ZV6130	X			
	Hewlett Packard	Business Notebook	NC2400 (65 watt models only)	503101			
	Hewlett Packard	Business Notebook	NC4400 (65 watt models only)	503101			
	Hewlett Packard	Business Notebook	NC4000	502936			
	Hewlett Packard	Business Notebook	NC4200	502936			
	Hewlett Packard	Business Notebook	NC6000	502936			
	Hewlett Packard	Business Notebook	NC6120	502936			
	Hewlett Packard	Business Notebook	NC6220	502936			
	Hewlett Packard	Business Notebook	NC6230	502938			
	Hewlett Packard	Business Notebook	NC6320 (65 watt models only)	503101			
	Hewlett Packard	Business Notebook	NC6325 (65 watt models only)	503101			
	Hewlett Packard	Business Notebook	NC6400 (65 watt models only)	503101			
	Hewlett Packard	Business Notebook	NC6440	X			
	Hewlett Packard	Business Notebook	NC7000	502936			
	Hewlett Packard	Business Notebook	NC8000	502936			
	Hewlett Packard	Business Notebook	NC8230	502936			
	Hewlett Packard	Business Notebook	NC8430 (65 watt models only)	503101			
	Hewlett Packard	Business Notebook	NX4800	502936			
	Hewlett Packard	Business Notebook	NX5000 Series	502936			
	Hewlett Packard	Business Notebook	NX6000 Series	502936			
	Hewlett Packard	Business Notebook	NX6110	502938			
	Hewlett Packard	Business Notebook	NX6115 (65 watt models only)	503101			
	Hewlett Packard	Business Notebook	NX6125	502938			
	Hewlett Packard	Business Notebook	NX6310	X			
	Hewlett Packard	Business Notebook	NX6320	X			
	Hewlett Packard	Business Notebook	NX7000 Series	502936			
	Hewlett Packard	Business Notebook	NX7300 (65 watt models only)	503101			
	Hewlett Packard	Business Notebook	NX7400 (65 watt models only)	503101			
	Hewlett Packard	Business Notebook	NX9000 Series	502936			
	Hewlett Packard	Business Notebook	NX9020	502936			
	Hewlett Packard	Business Notebook	NX9030	502936			
	Hewlett Packard	Business Notebook	NX9040	502936			
	Hewlett Packard	Business Notebook	NX9105	X			
	Hewlett Packard	Business Notebook	NX9420	X			
	Hewlett Packard	Business Notebook	NX9600	X			
	Hewlett Packard	Business Notebook	NW8240	502936			
	Hewlett Packard	Notebook PC	510 (65 watt models only)	503101			
	Hewlett Packard	Notebook PC	530 (65 watt models only)	503101			

Series	Manufacturer	Model	Number	Cable			
IBM							
For Lenovo T60, R60 and X60 models: Use the notebook's ac adapter to charge the notebook's internal battery. The N-Charge can be plugged in to the notebook when performing this operation. Do NOT use the N-charge to charge the notebook's internal battery.							
	IBM	Thinkpad	240	502289			
	IBM	Thinkpad	290	502289			
	IBM	Thinkpad	355	X			
	IBM	Thinkpad	360	X			
	IBM	Thinkpad	365 Series	502289			
	IBM	Thinkpad	380	502289			
	IBM	Thinkpad	380CE	502289			
	IBM	Thinkpad	380CS	502289			
	IBM	Thinkpad	380CSE	502289			
	IBM	Thinkpad	380D	502289			
	IBM	Thinkpad	380D-MMX	502289			
	IBM	Thinkpad	380E	502289			
	IBM	Thinkpad	380ED	502289			
	IBM	Thinkpad	380XD	502289			
	IBM	Thinkpad	380Z	502289			
	IBM	Thinkpad	385 Series	502289			
	IBM	Thinkpad	390 Series	502289			
	IBM	Thinkpad	560 Series	502289			
	IBM	Thinkpad	570 Series	502289			
	IBM	Thinkpad	600 Series	502289			
	IBM	Thinkpad	700	X			
	IBM	Thinkpad	701 Series	502289			
	IBM	Thinkpad	720	X			
	IBM	Thinkpad	750	X			
	IBM	Thinkpad	755	X			
	IBM	Thinkpad	760	X			
	IBM	Thinkpad	765	X			
	IBM	Thinkpad	770 Series	502289			
	IBM	Thinkpad	A Series	502289			
	IBM	Thinkpad	G Series	X			
	IBM	Thinkpad	T Series (up to T43)	502289			
	IBM	Thinkpad	T20	502289			
	IBM	Thinkpad	T30	502289			
	IBM	Thinkpad	T40	502289			
	IBM	Thinkpad	T41	502289			
	IBM	Thinkpad	T42	502289			
	IBM	Thinkpad	T43	502289			
	IBM	Thinkpad	T60 (Lenovo)	503100			
	IBM	Thinkpad	R Series (up to R52)	502289			
	IBM	Thinkpad	R40	502289			
	IBM	Thinkpad	R50	502289			
	IBM	Thinkpad	R51	502289			
	IBM	Thinkpad	R52	502289			
	IBM	Thinkpad	R60 (Lenovo)	503100			
	IBM	Thinkpad	X Series	502289			
	IBM	Thinkpad	X20	502289			
	IBM	Thinkpad	X21	502289			
	IBM	Thinkpad	X22	502289			
	IBM	Thinkpad	X23	502289			
	IBM	Thinkpad	X24	502289			
	IBM	Thinkpad	X30	502289			
	IBM	Thinkpad	X31	502289			
	IBM	Thinkpad	X32	502289			
	IBM	Thinkpad	X40	502289			
	IBM	Thinkpad	X41	502289			
	IBM	Thinkpad	X60t (Lenovo)	503100			
	IBM	Thinkpad	Z Series (Lenovo)	X			
	IBM	Thinkpad	Z60m (Lenovo)	X			
	IBM	Thinkpad	Z60t (Lenovo)	X			

For Lenovo T60, R60 and X60 models: Use the notebook's ac adapter to charge the notebook's internal battery. The N-Charge can be plugged in to the notebook when performing this operation. Do NOT use the N-charge to charge the notebook's internal battery.

Series	Manufacturer	Model	Number	Cable			
	IBM	Thinkpad	TransNote	502289			
	IBM	Thinkpad I	1161	502289			
	IBM	Thinkpad I	1171	502289			
	IBM	Thinkpad I	1200	502289			
	IBM	Thinkpad I	1300	502289			
	IBM	Thinkpad I	1340	502289			
	IBM	Thinkpad I	1400	502289			
	IBM	Thinkpad I	1410	502537			
	IBM	Thinkpad I	1411	502537			
	IBM	Thinkpad I	1412	502537			
	IBM	Thinkpad I	1418	502289			
	IBM	Thinkpad I	1420	502289			
	IBM	Thinkpad I	1421	502289			
	IBM	Thinkpad I	1434	502537			
	IBM	Thinkpad I	1435	502537			
	IBM	Thinkpad I	1436	502537			
	IBM	Thinkpad I	1441	502289			
	IBM	Thinkpad I	1442	502289			
	IBM	Thinkpad I	1450	502537			
	IBM	Thinkpad I	1451	502537			
	IBM	Thinkpad I	1452	502537			
	IBM	Thinkpad I	1460	502289			
	IBM	Thinkpad I	1470	502537			
	IBM	Thinkpad I	1471	502537			
	IBM	Thinkpad I	1472	502537			
	IBM	Thinkpad I	1476	502289			
	IBM	Thinkpad I	1480	502289			
	IBM	Thinkpad I	1500	502289			
	IBM	Thinkpad I	1512	502289			
	IBM	Thinkpad I	1552	502289			
	IBM	Thinkpad I	1560	502289			
	IBM	Thinkpad I	1700	502289			
	IBM	Thinkpad I	1720	502289			
	IBM	Thinkpad I	1721	502289			
	IBM	Thinkpad I	1830	502289			
	IBM	Thinkpad I	1836	502289			
Lenovo							
Use the notebook's ac adapter to charge the notebook's internal battery. The N-Charge can be plugged in to the notebook when performing this operation. Do NOT use the N-charge to charge the notebook's internal battery.							
	Lenovo	3000	series	503100			
	Lenovo	3000	C series	503100			
	Lenovo	3000	N series	503100			
	Lenovo	3000	V series	503100			
	Lenovo	Thinkpad	R60	503100			
	Lenovo	Thinkpad	T60	503100			
	Lenovo	Thinkpad	X60	503100			
	Lenovo	Thinkpad	Z60	X			
	Lenovo	Thinkpad	Z60t (Lenovo)	X			
	Lenovo	Thinkpad	Z60m (Lenovo)	X			
Medion							
	Medion		MD9783	502938			
Micron							
	Micron		T2100	502938			
	Micron		T3000	502938			
	Micron		GX	502795			
	Micron		VX	502795			
	Micron		T2000	X			
	Micron		X1000	X			
	Micron		X3000	502938			
Motion Computing							
	Motion Computing	Tablet PC's	m1200	502938			

Series	Manufacturer	Model	Number	Cable			
	Motion Computing	Tablet PC's	m1300	502938			
	Motion Computing	Tablet PC's	m1400	502938			
	Motion Computing	Tablet PC's	LE1600	502938			
	Motion Computing	Tablet PC's	LE1700	502938			
NEC							
	NEC	Versa	Lightpad Tablet PC	502938			
	NEC	Versa	LX	502444			
	NEC	Versa	SX	502938			
Neoware							
	Neoware	Thin Client Notebook	M100	502938			
Nobilis							
	Nobilis		244110	502938			
	Nobilis		N2007	502938			
Packard Bell							
	Packard Bell	Easy One	DC	502938			
Panasonic							
	Panasonic		C4F8	502442			
	Panasonic		CF01+	502442			
	Panasonic		CF25+	502442			
	Panasonic		CF27+	502442			
	Panasonic		CF28+	502442			
	Panasonic		CF33+	502442			
	Panasonic		CF34+	502442			
	Panasonic		CF35+	502442			
	Panasonic		CF37+	502442			
	Panasonic		CF45+	502442			
	Panasonic		CF47+	502442			
	Panasonic		CF48+	502442			
	Panasonic		CF50+	502289			
	Panasonic		CF61+	502442			
	Panasonic		CF62+	502442			
	Panasonic		CF71+	502442			
	Panasonic		Toughbook CF17	502442			
	Panasonic		Toughbook CF18	502289			
	Panasonic		Toughbook CF19	502289			
	Panasonic		Toughbook CF29	502289			
	Panasonic		Toughbook CF34	502442			
	Panasonic		Toughbook CF37	502442			
	Panasonic		Toughbook CF41	502442			
	Panasonic		Toughbook CF42	502442			
	Panasonic		Toughbook CF50	502289			
	Panasonic		Toughbook CF51	502289			
	Panasonic		Toughbook CF61	502442			
	Panasonic		Toughbook CF62	502442			
	Panasonic		Toughbook CF72	502442			
	Panasonic		Toughbook CF73	502289			
	Panasonic		Toughbook CF74	502289			
	Panasonic		Toughbook MDWD2	502289			
	Panasonic		Toughbook T5	502289			
	Panasonic		P1	502442			
PDS							
	PDS	Voyager	4S	502938			
	PDS	Voyager	M3	502938			
Sharp							
	Sharp	Actius	AV Series	502938			
	Sharp	Actius	GP Series	X			
	Sharp	Actius	MM Series	X			
	Sharp	Actius	MV Series	502938			
	Sharp	Actius	RD Series	X			
	Sharp	Actius	UM Series	X			
Sony							
	Sony	Vaio	PCG-B1XP	502442			
	Sony	Vaio	VGN-BX660	502443			
	Sony	Vaio	PCG-C Series	X			
	Sony	Vaio	PCG-F Series	502443			

Series	Manufacturer	Model	Number	Cable			
	Sony	Vaio	VGN-FS	502443			
	Sony	Vaio	VGN-FJ Series	502443			
	Sony	Vaio	PCG-FR Series	X			
	Sony	Vaio	PCG-FRV Series	X			
	Sony	Vaio	PCG-FX Series	502443			
	Sony	Vaio	PCG-GR Series	502442			
	Sony	Vaio	PCG-GRS Series	502443			
	Sony	Vaio	PCG-GRT Series	X			
	Sony	Vaio	PCG-GRV Series	X			
	Sony	Vaio	PCG-GRV 550	X			
	Sony	Vaio	PCG-GRV 670	X			
	Sony	Vaio	PCG-GRV 680	X			
	Sony	Vaio	PCG-GRX Series	X			
	Sony	Vaio	PCG-GRZ Series	X			
	Sony	Vaio	VGN-K13	502443			
	Sony	Vaio	PCG-SR Series	502442			
	Sony	Vaio	VGN-S18GP	502442			
	Sony	Vaio	PCG-TR Series	502442			
	Sony	Vaio	PCG-R505	502443			
	Sony	Vaio	PCG-S150	502442			
	Sony	Vaio	PCG-S170	502442			
	Sony	Vaio	PCG-S270	502442			
	Sony	Vaio	PCG-S360	502442			
	Sony	Vaio	VGN-SZ series	502443			
	Sony	Vaio	PCG-T140	502442			
	Sony	Vaio	PCG-T150	502442			
	Sony	Vaio	PCG-T250	502442			
	Sony	Vaio	VGN-T350	502442			
	Sony	Vaio	PCG-V505	502442			
	Sony	Vaio	PCG-X505	502442			
	Sony	Vaio	PCG-VX Series	502442			
	Sony	Vaio	PCG-XG Series	502443			
	Sony	Vaio	PCG-Z1 Series	502442			
	Sony	Vaio	PCG-Z505 Series	502443			
	Sony	Vaio Picturebook	PCG-C1X	502442			
Toshiba							
	Toshiba		T200	502444			
	Toshiba	Libretto	50	502444			
	Toshiba	Libretto	70	502444			
	Toshiba	Libretto	100	502444			
	Toshiba	Libretto	110	502444			
	Toshiba	Libretto	U100	502444			
	Toshiba	Portege	2000	502444			
	Toshiba	Portege	300	502444			
	Toshiba	Portege	320	502444			
	Toshiba	Portege	3010	502445			
	Toshiba	Portege	3015	502445			
	Toshiba	Portege	3020	502445			
	Toshiba	Portege	3025	502445			
	Toshiba	Portege	3110	502445			
	Toshiba	Portege	3120	502445			
	Toshiba	Portege	3440	502445			
	Toshiba	Portege	3480	502445			
	Toshiba	Portege	3490CT	502445			
	Toshiba	Portege	3500 Tablet PC	502444			
	Toshiba	Portege	3505 Tablet PC	502444			
	Toshiba	Portege	4000 Series	502444			
	Toshiba	Portege	4005 Series	502444			
	Toshiba	Portege	4010	502444			
	Toshiba	Portege	610	502444			
	Toshiba	Portege	620	502444			
	Toshiba	Portege	650	502444			
	Toshiba	Portege	660	502444			
	Toshiba	Portege	7000	502444			
	Toshiba	Portege	7010	502444			

Series	Manufacturer	Model	Number	Cable			
	Toshiba	Portege	7020	502444			
	Toshiba	Portege	7030	502444			
	Toshiba	Portege	7140	502444			
	Toshiba	Portege	7200	502444			
	Toshiba	Portege	7220	502444			
	Toshiba	Portege	7220Cte	502444			
	Toshiba	Portege	M100	502444			
	Toshiba	Portege	M115	502444			
	Toshiba	Portege	M200	502444			
	Toshiba	Portege	M400	502444			
	Toshiba	Portege	R100	502444			
	Toshiba	Portege	R200	502444			
	Toshiba	Portege	S100	502444			
	Toshiba	Satellite	1000	502938			
	Toshiba	Satellite	1005	502938			
	Toshiba	Satellite	1110	502938			
	Toshiba	Satellite	1115	502938			
	Toshiba	Satellite	1130	502938			
	Toshiba	Satellite	1200	502444			
	Toshiba	Satellite	1400 Series	502444			
	Toshiba	Satellite	1555	502444			
	Toshiba	Satellite	1605	502938			
	Toshiba	Satellite	1615	502444			
	Toshiba	Satellite	1625	502938			
	Toshiba	Satellite	1675CDS	502938			
	Toshiba	Satellite	1695CDT	502938			
	Toshiba	Satellite	1715	502938			
	Toshiba	Satellite	1715XCDS	502938			
	Toshiba	Satellite	1730	502938			
	Toshiba	Satellite	1735	502938			
	Toshiba	Satellite	1750	502938			
	Toshiba	Satellite	1755	502938			
	Toshiba	Satellite	1800	502444			
	Toshiba	Satellite	1805	502444			
	Toshiba	Satellite	1900 Series	X			
	Toshiba	Satellite	1900	X			
	Toshiba	Satellite	1905	X			
	Toshiba	Satellite	1955	X			
	Toshiba	Satellite	2010	502444			
	Toshiba	Satellite	2060	502444			
	Toshiba	Satellite	2065	502444			
	Toshiba	Satellite	2095	502444			
	Toshiba	Satellite	2100	502444			
	Toshiba	Satellite	2105	502444			
	Toshiba	Satellite	210CS	502444			
	Toshiba	Satellite	2140	502444			
	Toshiba	Satellite	2180	502444			
	Toshiba	Satellite	220	502444			
	Toshiba	Satellite	2210	502444			
	Toshiba	Satellite	225	502444			
	Toshiba	Satellite	2250	502444			
	Toshiba	Satellite	230CX	502444			
	Toshiba	Satellite	2400	502444			
	Toshiba	Satellite	2410	502444			
	Toshiba	Satellite	2420	502938			
	Toshiba	Satellite	2430	X			
	Toshiba	Satellite	2450	X			
	Toshiba	Satellite	2455	X			
	Toshiba	Satellite	2505	502444			
	Toshiba	Satellite	2515	502444			
	Toshiba	Satellite	2520	502444			
	Toshiba	Satellite	2525	502444			
	Toshiba	Satellite	2535	502444			
	Toshiba	Satellite	2540	502444			
	Toshiba	Satellite	2545	502444			

Series	Manufacturer	Model	Number	Cable			
	Toshiba	Satellite	2590	502444			
	Toshiba	Satellite	2595	502444			
	Toshiba	Satellite	2610	502444			
	Toshiba	Satellite	2615	502444			
	Toshiba	Satellite	2650XDVD	502444			
	Toshiba	Satellite	2655	502444			
	Toshiba	Satellite	2675	502444			
	Toshiba	Satellite	2715	502444			
	Toshiba	Satellite	2755	502444			
	Toshiba	Satellite	2775	502444			
	Toshiba	Satellite	2800	502444			
	Toshiba	Satellite	2800T	502444			
	Toshiba	Satellite	2805	502444			
	Toshiba	Satellite	305	502444			
	Toshiba	Satellite	3000	502938			
	Toshiba	Satellite	3005	502938			
	Toshiba	Satellite	315	502444			
	Toshiba	Satellite	320	502444			
	Toshiba	Satellite	325	502444			
	Toshiba	Satellite	330	502444			
	Toshiba	Satellite	335	502444			
	Toshiba	Satellite	4000	502444			
	Toshiba	Satellite	4005	502444			
	Toshiba	Satellite	4010	502444			
	Toshiba	Satellite	4015	502444			
	Toshiba	Satellite	4020	502444			
	Toshiba	Satellite	4025	502444			
	Toshiba	Satellite	4030	502444			
	Toshiba	Satellite	4060	502444			
	Toshiba	Satellite	4070	502444			
	Toshiba	Satellite	4080	502444			
	Toshiba	Satellite	4090	502444			
	Toshiba	Satellite	4100	502444			
	Toshiba	Satellite	4320	502444			
	Toshiba	Satellite	4340	502444			
	Toshiba	Satellite	4360	502444			
	Toshiba	Satellite	4600	502444			
	Toshiba	Satellite	5005 Series	502444			
	Toshiba	Satellite	5105 Series	502444			
	Toshiba	Satellite	5200 Series	502444			
	Toshiba	Satellite	A10	502444			
	Toshiba	Satellite	A15	502444			
	Toshiba	Satellite	A20	X			
	Toshiba	Satellite	A25	X			
	Toshiba	Satellite	A50	502444			
	Toshiba	Satellite	A55	502444			
	Toshiba	Satellite	M20	502444			
	Toshiba	Satellite	M30	502444			
	Toshiba	Satellite	M35	502444			
	Toshiba	Satellite	M40	502444			
	Toshiba	Satellite	M45-S265	502444			
	Toshiba	Satellite	M45-S331	502444			
	Toshiba	Satellite	M45-S359	502444			
	Toshiba	Satellite	M50	502444			
	Toshiba	Satellite	M55	502444			
	Toshiba	Satellite	M30X	502938			
	Toshiba	Satellite	M35X	502938			
	Toshiba	Satellite	P10	X			
	Toshiba	Satellite	P25	X			
	Toshiba	Satellite	R10	502444			
	Toshiba	Satellite	R15	502444			
	Toshiba	Satellite	ST10	502938			
	Toshiba	Satellite	U200	502444			
	Toshiba	Satellite Pro	4220	502444			
	Toshiba	Satellite Pro	4260	502444			

Series	Manufacturer	Model	Number	Cable			
	Toshiba	Satellite Pro	4280	502444			
	Toshiba	Satellite Pro	4300	502444			
	Toshiba	Satellite Pro	440	502444			
	Toshiba	Satellite Pro	445	502444			
	Toshiba	Satellite Pro	460	502444			
	Toshiba	Satellite Pro	4600	502444			
	Toshiba	Satellite Pro	465	502444			
	Toshiba	Satellite Pro	480	502444			
	Toshiba	Satellite Pro	490	502444			
	Toshiba	Satellite Pro	490X	502444			
	Toshiba	Satellite Pro	6000	502444			
	Toshiba	Satellite Pro	6100	502444			
	Toshiba	Satellite Pro	M10-S405	502444			
	Toshiba	Satellite Pro	M15-S405	502444			
	Toshiba	Tecra	510CDT	502444			
	Toshiba	Tecra	520	502444			
	Toshiba	Tecra	520CDT	502444			
	Toshiba	Tecra	530	502444			
	Toshiba	Tecra	550	502444			
	Toshiba	Tecra	700	502444			
	Toshiba	Tecra	710	502444			
	Toshiba	Tecra	720	502444			
	Toshiba	Tecra	720CDT	502444			
	Toshiba	Tecra	730	502444			
	Toshiba	Tecra	730X	502444			
	Toshiba	Tecra	740	502444			
	Toshiba	Tecra	750	502444			
	Toshiba	Tecra	780	502444			
	Toshiba	Tecra	8000	502444			
	Toshiba	Tecra	8100	502444			
	Toshiba	Tecra	8200	502444			
	Toshiba	Tecra	9000	502444			
	Toshiba	Tecra	9100	502444			
	Toshiba	Tecra	A1	502444			
	Toshiba	Tecra	A2	502444			
	Toshiba	Tecra	A3	502444			
	Toshiba	Tecra	A4	502444			
	Toshiba	Tecra	A5	502444			
	Toshiba	Tecra	A6	502444			
	Toshiba	Tecra	A7	502444			
	Toshiba	Tecra	A8	502444			
	Toshiba	Tecra	L2				
	Toshiba	Tecra	M1	502444			
	Toshiba	Tecra	M2	502444			
	Toshiba	Tecra	M2V	502444			
	Toshiba	Tecra	M3	502444			
	Toshiba	Tecra	M4	502444			
	Toshiba	Tecra	M5	502444			
	Toshiba	Tecra	M7	502444			
	Toshiba	Tecra	S1	502444			
	Toshiba	Tecra	S2	502444			
	Toshiba	Tecra	TE 2000	502444			
	Toshiba	Tecra	TE 2100	502444			
	Toshiba	Tecra	TE 2300	502444			
	Toshiba	Qosmio	F20	502444			
			Twinhead				
	Twinhead		P88T	502938			
	Twinhead		N222S	502938			
	Twinhead		N1400	502938			
	Twinhead		2380	502938			
	Twinhead		340S8	502938			
			ViewSonic				
	ViewSonic		Tablet PC V1250	502285			
			Vpr				
	Vpr	Matrix	185A5	502938			

Series	Manufacturer	Model	Number	Cable			
	Vpr	Matrix	200A5	502938			
	Winbook						
	Winbook		C120	502938			
	Winbook		C140	502938			
	Winbook		C170	502938			
	Winbook		FX	502537			
	Winbook		XP5 Pro	502537			
	Winbook		J1	502938			
	Winbook		J4	X			
	Winbook		Si	502938			
	Winbook		Si2	502938			
	Winbook		W140	502938			
	Winbook		W160	502938			
	Winbook		X1	502938			
	Winbook		XP	502938			
	Winbook		XP5	502938			
	Winbook		Z1	502938			
	Winbook		X1i	502285			
	Winbook		XL	502285			
	Winbook		XL2	502285			
	Winbook		XL3	502285			